


BSL77F

ProCage™ “Black Series” 7’x7’ Square Screen ASSEMBLY INSTRUCTIONS

BOX CONTENTS


Part No. & Description	Quantity
• Part #1 Elbow piece with two reduced ends	2 each
• Part #2 pieces with one reduced ends	4 each
• Part #3 piece with two reduced ends	1 each
• Part #4 piece with two open ends	1 each
• Part #5 4-Way bottom leg pieces with open ends	2 each
• Pillowcase-style net with lacing cord	1 each



Note: Nets and frame should be inspected prior to each use. **DO NOT** use protective screen if holes are present in the netting. Repair or replace net before use. This screen **IS NOT** designed for short toss or close hitting drills. For use of this protective screen in batting cage setting we recommend adding Item # **B77PAD** kit designed for this frame.

Please call 888-313-1303 to order or visit us on the web www.trigonsports.com.


STEP 1



Using diagram shown, start by joining Part #3 and Part #2 with Part #5 4-way leg pieces on each end using push button assembly.


NOTE: Be sure Part #5, 4-way bottom leg pieces form a 'V' off the ground.

STEP 2




Attach Part #2 on each side using push buttons.

STEP 3



Assemble top half of frame by joining Part #2 and Part #4 with (1) Part #1 elbow pieces on each end.


STEP 4



Join top half with bottom half of frame assembly.

NOTE: Be sure all push buttons on frame are seated properly.

ASSEMBLED SCREEN



Install net by sliding over top frame. Net should fit like a "pillowcase". Use lacing twine provided to secure net opening to bottom rail.